

S20 COMPATIBILITY CHART

Our S 20 is compatible with 99% of existing firing systems. Anyway you can easily check if your firing systems in compatible with our S 20 sequencer; just compare the output voltage and current of the cues of your firing system, with those requested by S 20. If one of 4 range match, then the S 20 is compatible with your system!

EXAMPLE:

For this output voltage range..



6 - 24 V

...is requested a minimum output current of:



0,7A

If your firing system has got an output voltage value included into 1 of the 4 range showed below, and its corresponding current value is **equal or higher** of that indicated in that range, then the S 20 sequencer is 100% compatible with your firing system.

VOLTAGE / MINIMUM CURRENT REQUESTED

6 - 24 V	24 - 40 V	40- 60 V	60 - 80 V
0,8 A	1,7 A	2,5 A	5 A

If the output voltage / current of your firing system does not match with those showed into the table, please contact us: you can use also intermediate values we will show to you, depending on your voltage and current values.